```
#include <WiFi.h>
#include "ThingSpeak.h"
and find the thingspeak channel I am uploading to
char ssid[] = "Baggadown";
const char password[] = "EscomP75!!";
const unsigned long channel id = 1626364;
const char write api key[] = "FOTQWKESYHKVYSW8";
WiFiClient client;
void setup() {
 Serial.begin(9600);
 delay(80);
 Serial.print("Connecting to ");
 Serial.println(ssid);
 WiFi.begin(ssid, password);
 while (WiFi.status() != WL CONNECTED) {
   delay(500);
    Serial.println("Not Connected");
 Serial.println("Connected Sucessfully");
 ThingSpeak.begin(client);
  pinMode(0, INPUT);
```

```
void loop() {
  int analogValue = analogRead(0);
  if (analogValue < 10) {</pre>
    Serial.println(" - Dark");
     Serial.println(analogValue);
    Serial.println("");
  } else if (analogValue < 20) {</pre>
    Serial.println(" - Dim");
    Serial.println(analogValue);
    Serial.println("");
  } else if (analogValue < 50) {</pre>
    Serial.println(" - Light");
    Serial.println(analogValue);
    Serial.println("");
  } else if (analogValue < 80) {</pre>
    Serial.println(" - Bright");
    Serial.println(analogValue);
    Serial.println("");
    Serial.println(" - Very bright");
  ThingSpeak.setField(1, String(analogValue));
  ThingSpeak.writeFields(channel id, write api key);
  delay(1000);
```